Lock-n-Haul Delrin End Installation

1. Place cupped end down on solid flat surface.
2. Align aluminum tube over drilled end.
3. Take care to keep the aluminum tube straight and perpendicular to the flat surface.
4. Use a soft mallet or piece of solid wood to drive the tube straight down into the end.
5. If installing a round end, place tube end on flat surface, and drive the round end onto it.

Lock-n-Haul Delrin End Installation

1. Place cupped end down on solid flat surface.
2. Align aluminum tube over drilled end.
3. Take care to keep the aluminum tube straight and perpendicular to the flat surface.
4. Use a soft mallet or piece of solid wood to drive the tube straight down into the end.
5. If installing a round end, place tube end on flat surface, and drive the round end onto it.

Lock-n-Haul Delrin End Installation

1. Place cupped end down on solid flat surface.
2. Align aluminum tube over drilled end.
3. Take care to keep the aluminum tube straight and perpendicular to the flat surface.
4. Use a soft mallet or piece of solid wood to drive the tube straight down into the end.
5. If installing a round end, place tube end on flat surface, and drive the round end onto it.

Lock-n-Haul Delrin End Installation

1. Place cupped end down on solid flat surface.
2. Align aluminum tube over drilled end.
3. Take care to keep the aluminum tube straight and perpendicular to the flat surface.
4. Use a soft mallet or piece of solid wood to drive the tube straight down into the end.
5. If installing a round end, place tube end on flat surface, and drive the round end onto it.

Lock-n-Haul Delrin End Installation

1. Place cupped end down on solid flat surface.
2. Align aluminum tube over drilled end.
3. Take care to keep the aluminum tube straight and perpendicular to the flat surface.
4. Use a soft mallet or piece of solid wood to drive the tube straight down into the end.
5. If installing a round end, place tube end on flat surface, and drive the round end onto it.

Lock-n-Haul Delrin End Installation

1. Place cupped end down on solid flat surface.
2. Align aluminum tube over drilled end.
3. Take care to keep the aluminum tube straight and perpendicular to the flat surface.
4. Use a soft mallet or piece of solid wood to drive the tube straight down into the end.
5. If installing a round end, place tube end on flat surface, and drive the round end onto it.

Lock-n-Haul Delrin End Installation

1. Place cupped end down on solid flat surface.
2. Align aluminum tube over drilled end.
3. Take care to keep the aluminum tube straight and perpendicular to the flat surface.
4. Use a soft mallet or piece of solid wood to drive the tube straight down into the end.
5. If installing a round end, place tube end on flat surface, and drive the round end onto it.

Lock-n-Haul Delrin End Installation

1. Place cupped end down on solid flat surface.
2. Align aluminum tube over drilled end.
3. Take care to keep the aluminum tube straight and perpendicular to the flat surface.
4. Use a soft mallet or piece of solid wood to drive the tube straight down into the end.
5. If installing a round end, place tube end on flat surface, and drive the round end onto it.

Lock-n-Haul Delrin End Installation

1. Place cupped end down on solid flat surface.
2. Align aluminum tube over drilled end.
3. Take care to keep the aluminum tube straight and perpendicular to the flat surface.
4. Use a soft mallet or piece of solid wood to drive the tube straight down into the end.
5. If installing a round end, place tube end on flat surface, and drive the round end onto it.

Lock-n-Haul Delrin End Installation

1. Place cupped end down on solid flat surface.
2. Align aluminum tube over drilled end.
3. Take care to keep the aluminum tube straight and perpendicular to the flat surface.
4. Use a soft mallet or piece of solid wood to drive the tube straight down into the end.
5. If installing a round end, place tube end on flat surface, and drive the round end onto it.